

WALKING POLE CONVERTER

ONE PLANET

FOR 2MIDABLE AND 4MIDABLE

The walking pole converter for the 2Midable and 4Midable allows you to use a pair of walking poles as the tent's centre pole, saving weight. The converter conveniently doubles as your peg bag.

This converter creates an easily adjustable pole for ONE PLANET pyramid tents using either folding or telescopic walking poles. Connecting opposing ends of the poles with maximum crossover ensures structural integrity with minimal lateral flex.



SETUP INSTRUCTIONS



- 1 First, remove pegs. Place the foot of one pole into the bag's pole section.



- 2 Place the handle of the second pole into the peg section.



- 3 Wrap hook-and-loop straps around both poles, securing firmly. Use the side-release buckle to clip in adjustment webbing.



- 4 Using the webbing, adjust to the desired height.



- 5 Place assembled pole into your tent with handle at the apex and foot in the ground.

ONE PLANET

650 Somerville Road
Sunshine West VIC 3020
P | 03 9311 5244
E | sales@oneplanet.com.au

Any further questions?

If you have any further questions on fitting your walking pole converter or you would like to see other products in our range, visit oneplanet.com.au